

Thank you for purchasing these Sunbeam® Wireless Linkable LED Wall Lights. Please read all instructions before using your new Wireless Linkable LED Wall Lights.


IMPORTANT: FOR INDOOR AND DRY LOCATION USE ONLY. ADHESIVE TAPE MAY DAMAGE SURFACE IF REMOVED.

SPECIFICATIONS

Battery type: AA *3 per unit

Rating: max 1W, 4.5V / DC, 2.4 GHz

PARTS



3 LED wall lights
10 L x 8 W x 3 H cm
3.94 L x 3.15 W x 1.18 H in



9 Alkaline
AA batteries



3 Double-sided foam
adhesive tapes
5 L x 4 W cm / 1.96 L x 1.57 W in



6 Drywall screws 2 cm / 0.79 in
and anchors



6 Wood screws
1.2 cm / 0.47 in

FUNCTIONS





Photo and Motion
sensor


Timer
switch



Linking indicator light

On / Off /
Linking /
Pairing
button

SENSING RANGE



Motion sensor detection distance: 3 - 5 m / 9.84 - 16.4 ft

Detection angle: 100°

Maximum distance between 2 units: 8 m / 26.2 ft

Photo and Motion Sensor Light

Light automatically turns on when sensor detects motion and there is a lack of ambient light; automatically turns off when no motion is detected within the selected time or there is sufficient ambient light.

Adjustable Timer

Light automatically turns off if no motion is detected by motion sensor for 15 / 30 / 45 seconds based on timer switch position.

Linking Indicator Light

The units are linked when the red linking indicator light is blinking. Linked units will turn on when one of the units detects motion in low ambient light.

Low Battery Indicator

When batteries are running low, the unit will flash for 10 seconds when it detects motion in low ambient light. This signals that battery replacement is needed.

NOTE: A unit in a room with sufficient ambient light will not illuminate.

IMPORTANT SAFETY INSTRUCTIONS

This device complies with Part 15 of the FCC Rules and Industry Canada's licence-exempt RSSs. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

WARNING: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio / TV technician for help.

BATTERY INSTRUCTIONS & CAUTIONS: Always purchase the correct size and grade of battery most suitable for the intended use. Always replace the whole set of batteries at one time, taking care not to mix old and new ones, or batteries of different types. Clean the battery contacts and also those of the device prior to battery installation. Ensure the batteries are installed correctly with regard to polarity (+ and -). Remove batteries from equipment which is not to be used for an extended period of time. Remove used batteries promptly. For recycling and disposal of batteries to protect the environment, please check the internet or your local phone directory for local recycling centers and / or follow local government regulations.

For information about ordering parts or how to expand your kit, please call us at 1-877-383-6399 (8:30 am - 5:30 pm E.S.T.) Monday - Friday or contact us at www.limagehomeproducts.com

If you have any problems, please do not contact the store. Our customer service will be happy to assist you.

LIMITED WARRANTY

This product is guaranteed to operate a minimum of 1 year from the original date of purchase. If, under normal use and for the full time period, your product fails to operate, please return it to: Quality Control Dept., L'Image Home Products, Inc., 1175 Place du Frère-André, Montreal, Quebec, Canada H3B 3X9 (with your original proof of purchase receipt) and we will refund it. This warranty is considered void if the product fails from misuse.

Distributed by:
Costco Wholesale Corporation
P.O. Box 34535
Seattle, WA 98124-1535
USA
1-800-774-2678
www.costco.com

© 2017 Sunbeam Products, Inc. doing business as Jarden Consumer Solutions. All rights reserved. SUNBEAM® logo is a registered trademark of Sunbeam Products, Inc. used under license. Distributed by L'Image Home Products Inc., Montreal, Canada H3B 3X9. LHP1115-090117

MADE IN CHINA

SAVE THESE INSTRUCTIONS

SETUP AND INSTALLATION

Before installation, make sure the surface you intend to mount the product on is free of moisture, oil, grease, dust and dirt to ensure proper adhesion. Test painted surfaces. Adhesive tape may damage surface when removing.

SETUP

There are 2 ways to operate the units.

A. Stand-alone unit: Set the timer switch to the desired light duration (FIG. 1). Insert 3 batteries in each unit (FIG. 2). Press the On / Off button once, the light will turn on (FIG. 3). If there is sufficient ambient light or no motion is detected, the light will turn off when the preset time has elapsed.

B. Linked with other unit(s): Set the timer switch to the desired light duration (FIG. 1). Press the On / Off button twice (FIG. 4). The linking indicator light will turn on and flash, indicating the unit(s) are linked (FIG. 5). Repeat for all other units. Linked units will turn on when one of the units detects motion in low ambient light.

To unlink a unit, press the On / Off button once. The linking indicator light will turn off.

NOTE: A unit in a room with sufficient ambient light will not illuminate.

NOTE: Linkable up to 10 units, maximum 8 m / 26.2 ft between 2 units.

INSTALLATION

There are 3 ways to mount the unit.

A. Double-sided foam adhesive tape:

Mark the desired area where you want to install. Remove one side of the tape and secure to the back of the LED light. Then remove the other side of the tape and secure to where you want to install (FIG. 6).

B. Drywall surface mounting anchor screw:

Place the mounting plate over the desired mounting location and mark the center of the holes to be drilled. Drill two pilot holes 0.45 - 0.50 cm / 0.18 - 0.20 in diameter into the surface. Insert the anchors. Place the mounting plate over the holes and screw in the mounting screws 2 cm / 0.79 in to secure (FIG. 7).

C. Wood surface mounting screw:

Place the mounting plate over the desired mounting location and mark the center of the holes to be drilled. Then place the mounting plate over the marks and screw in the mounting screws 1.2 cm / 0.47 in to secure (FIG. 8).

NOTE: To prevent damage to the wall, use adhesive glue remover. Follow the manufacturer's instructions.

If you have purchased more than one pack and want to link more than 3 units, please follow pairing instructions below.

PAIRING ADDITIONAL UNITS

All units within the package are already paired at the time of purchase.

STEP 1

Designate one of the units as your master unit:

First, insert 2 batteries (FIG. 9). When inserting the 3rd battery, press and hold the On / Off button (FIG. 10). The red linking indicator light will flash, indicating the unit is ready to be paired (FIG. 12).

STEP 2

Pairing new units with the master unit:

Insert all 3 batteries into the unit to be paired. Press and hold the On / Off button (FIG. 11). The unit light will flash 2 times within 3 seconds. Pairing is now complete (FIG. 12). Release the On / Off button.

Repeat (STEP 2) for the next units to be paired.

NOTE: Pairing time limit (3 minutes): the linking indicator light of the master unit will turn off after 3 minutes. After 3 minutes, you will need to re-start the entire pairing procedure.

For troubleshooting tips or to download this instruction manual, please visit the product page on our website: www.limagehomeproducts.com

FIG. 1




FIG. 2




FIG. 3




FIG. 4




FIG. 5




FIG. 6




FIG. 7




FIG. 8




FIG. 9




FIG. 10




FIG. 11




FIG. 12

